
Slab ASE 01		-
Inputs:		
10	slab length (cm)	·
0.35	slab height (cm)	
0.25	slab thickness (cm)	
1.82	slab refractive index	
1.6	parasitic coating index	More than
0.08	specific gain (nepers/cm)	` <u> </u>
100000	number of rays to launch	1000 parastic
100000	number of rays to launch	Mays found of the
•		Jer.
		and what
Outoutou		Ou and from M. Co
Outputs:		and the stage of t
0.08	maximum gain (nepers/cm)	and to explu we
-21.9501	minimum gain (nepers/cm)	04 1 4 0 1171
		معلمن معرك سري ليل مبعديد
		The state of the s
	x .	
	\widehat{A}	It turder whole
	1	الله على تسريفين
	م سعد	
	205 MIN	
	3.5mm	2 a kind of
	· / 10	cm barrel mode
	/	Amma -+·
•	÷	polasilie
		\ exists
		- mora
		For n / 7n2-11/2
		2 1 3 72
		they can be
		parasitic mod
	2 -4 0	10 4.
For	Paraulie Mode:	parasilie mod
-	100	<i>[</i>
	have the	
Aver	age distance holder	parasitie mod veen strikes $\frac{3.5 \text{mm}}{.4} = 8.75 \text{mm}$
	y	yours
on	top and bottom	2 3.5mm 005
		= 8,/2mm
Λ	0 - 1	• • • • • • • • • • • • • • • • • • • •
Huer	rage distance In	and last the state of hou
m	0.1t.	~ ~ ~ Dewell gures
J. (up and right	welled between 8trkes sides ~ 2.5 mm = 6.25 mm
	o	-4 -6,22 FIM
Au	eras o - of	travelled between 2- ends = 10 cm = 12.2 cm
	· Jamaner	Travelled believe
A.	uber - 0 1	
00	on stat	- ends a Tour - 12 2 am
		,82 -16, CCM



```
Dim GainDistribution (1000)
Const pi As Double = 3.141592654
Sub Main()
' Main Macro
                        by Raymond J. Beach
' Macro recorded
' Keyboard Shortcut: Ctrl+u
'Get input parameters
    Worksheets ("sheet1") . Select
    Range("length").Select: SlabLength = ActiveCell.Value
    Range("height").Select: SlabHeight = ActiveCell.Value
    Range("thickness").Select: SlabThickness = ActiveCell.Value
    Range("slabindex").Select: SlabIndex = ActiveCell.Value
    Range("coatingindex").Select: CoatingIndex = ActiveCell.Value
    Range("specificgain").Select: SpecificGain = ActiveCell.Value
    Range("numberofrays").Select: NumberOfRays = ActiveCell.Value
'Define other parameters
    NumberOfParasiticDirections = 0
    Nbins = 100
    MaxGain = SpecificGain
    Range("maximumgain").Select: ActiveCell.Value = MaxGain
    RelativeIndex = SlabIndex / CoatingIndex
    If SlabHeight < SlabThickness Then
        MinGain = 2 * Log((RelativeIndex - 1) / (RelativeIndex + 1)) / SlabHeight
    Else
        MinGain = 2 * Log((RelativeIndex - 1) / (RelativeIndex + 1)) / SlabThickness
    Range("minimumgain").Select: ActiveCell.Value = MinGain
'Initialize the random number generator
    Randomize
'Start the launch cycle
For i = 1 To NumberOfRays
'Define a random launch direction in (+,+,+) quadrant using direction cosines to define the dire
tion
    Phi = (pi / 2) * Rnd
    Theta = (pi / 2) * Rnd
'x is the slab height direction
 'y is the slab thickness direction
 'z is the slab length direction
    cx = Sin(Theta) * Cos(Phi)
                                 'direction cos in x-direction
    cy = Sin(Theta) * Sin(Phi)
                                 'direction cos in y-direction
                                 'direction cos in z-direction
    cz = Cos(Theta)
'Define unpolarized Fresnel reflection coefficients for three different planes that generate im-
ge space
     'x-plane calculation
    Thetal = ArcCos(cx)
    Temp = SlabIndex * Sin(Theta1) / CoatingIndex
    If Abs(Temp) > 1 Then
        Refx = 1
    Else
        Theta2 = ArcSin(Temp)
        Refx = ((Sin(Theta1 - Theta2) / Sin(Theta1 + Theta2)) ^ 2 + (Tan(Theta1 - Theta2) / Tan
Theta1 + Theta2)) ^ 2) / 2
    End If
     'y-plane Calculation
     Thetal = ArcCos(cy)
    Temp = SlabIndex * Sin(Thetal) / CoatingIndex
    If Abs(Temp) > 1 Then
```

```
Refy = 1
   Else
       Theta2 = ArcSin(Temp)
       Refy = ((Sin(Thetal - Theta2) / Sin(Thetal + Theta2)) ^ 2 + (Tan(Thetal - Theta2) / Tan
Theta1 + Theta2)) ^ 2) / 2
    End If
    'z-plane calculation
    Thetal = ArcCos(cz)
    Temp = SlabIndex * Sin(Theta1)
    If Abs(Temp) > 1 Then
       Refz = 1
    Else
        Theta2 = ArcSin(Temp)
        Refz = ((Sin(Thetal - Theta2) / Sin(Thetal + Theta2)) ^ 2 + (Tan(Thetal - Theta2) / Tan
Theta1 + Theta2)) ^ 2) / 2
    End If
'Calculate the loss per cm in nepers/cm due to x, y, and z reflections
    Nepersx = cx * Log(Refx) / SlabHeight
    Nepersy = cy * Log(Refy) / SlabThickness
    Nepersz = cz * Log(Refz) / SlabLength
'Calculate the net gain-loss in nepers/cm seen by this ray
    Nepers = SpecificGain + Nepersx + Nepersy + Nepersz
'Bin this launch
    BinNumber = Nbins * (Nepers - MinGain) / (MaxGain - MinGain)
    If BinNumber < 0 Then BinNumber = 0
    GainDistribution(BinNumber) = GainDistribution(BinNumber) + 1
    If Nepers > 0 Then
        Beep
        NumberOfParasiticDirections = NumberOfParasiticDirections + 1
        Worksheets("sheet2").Cells(1 + NumberOfParasiticDirections, 1).Value = cx
        Worksheets("sheet2").Cells(1 + NumberOfParasiticDirections, 2).Value = cy
        Worksheets("sheet2").Cells(1 + NumberOfParasiticDirections, 3).Value = cz
        Worksheets("sheet2").Cells(1 + NumberOfParasiticDirections, 4).Value = Refx
        Worksheets("sheet2").Cells(1 + NumberOfParasiticDirections, 5).Value = Refy
        Worksheets("sheet2").Cells(1 + NumberOfParasiticDirections, 6).Value = Refz
        Check = Sgr(cx ^2 + cy ^2 + cz ^2)
     End If
Next i
End Sub
Function ArcCos(C)
'Returns the Arc Cos of C.
    If C = 0 Then
        ArcCos = pi / 2
        ArcCos = Atn(Sqr(1 - C ^ 2) / C)
    End If
End Function
Function ArcSin(S)
'Returns the Arc Sin of S
    If S = 1 Then
        ArcSin = pi / 2
        ArcSin = Atn(S / Sqr(1 - S^2))
    End If
End Function
```